



# Acer Aspire E3-111-C32T Hard Drive Drive Replacement

This guide will show you how to replace the HDD

Written By: Andrew Johnstone



## INTRODUCTION


This guide will show you how to replace the HDD

## Step 1 — Unscrew and remove all screws on the back



- Unscrew all screws, And remove.  
(Sorry for picture quality)

## Step 2



- Put laptop on its side
- But fingernail under usb port and pry and lift up until you hear a snap
- go around the laptop with your fingernail un doing every snap

To reassemble your device, follow these instructions in reverse order.